




## 二、SEARCH KEY OIV POWER⊕ , GND⊖ AND TPS SIGNAL 0~5V ◦

### 1、KEY POWER⊕ :




### STEP 1




### STEP 2




### STEP 3



三、GND⊖ : HANG ON GND




STEP 4




四、AS BELOW


STEP 5




STEP 6



STEP 7



STEP 8



LEFT SIDE  
PLEASE PLUG IT