

# GALLARDO INSTALLATION MANUAL


一、REMOTE CONTROL SYSTEM FOR YOUR REFERENCE.

1. YELLOW CABLE: TPS VOLTAGE SIGNAL 0~5V

2. BROWN CABLE: GND



3. RED CABLE: KEY ON SWITCH

4. ELECTRONIC VALVE



二、CONNECT WITH TPS VOLTAGE SIGNAL 0~5V、KEY ON SWITCH AND GND.

1、OPEN DRIVER'S DOOR AND YOU CAN FIND ELECTRONIC ACCELERATOR IN THE BACK OF GAS PEDAL.THEN CONNECT WITH TPS AND YELLOW/WHITE CABLE.



2、CONNECT WITH PURPLE CABLE OF ELECTRONIC VALVE、KEY ON SWITCH  
(RED CABLE) AND HANG ON GND.

